

尺寸:75X105mm 注意导圆角

按键指示说明

指示灯
感光元件
红外灯
微距摄像头
摄像头1
麦克风
红外灯
白光灯
红蓝爆闪灯
TYPE-C接口
推上录像/
推下停止录像
PTT对讲键
录音键
电源键
电池锁扣
更换电池手扣位
摄像头2
显示屏
菜单
主页
返回
标记文件
拍照/红外灯键
白光灯/音量+
FN/音量-
SOS键

功能按键快捷说明

①【录像键】推上开始录像,推下结束录像;②【PTT对讲键】一对一对讲,终端设备与平台端语音对讲;③【录音键】短按开始或者结束录音;④【电源键】长按三秒,即可开、关机,重启;点按打开、关闭屏幕,关闭屏幕后进入待机;⑤【重点标记键】按一下对正在进行的录像录音文件进行IMP标记,重要标记;⑥【拍照/红外灯键】短按拍照,长按打开或关闭红外灯

⑦【白光灯/音量+键】短按调节音量+,长按打开或者关闭白光灯;⑧【FN/音量-键】短按调节音量-;⑨【SOS键】按一下向平台推送救助信号,同时开启红蓝爆闪灯,对SOS状态下录像,录音,拍照等产生的文件进行SOS标记,重要标记,平台云服务同时存储文件。

KEY INDICATION

indicator light
photosensitive element
infrared lamp
Macro camera
camera1
microphone
infrared lamp
white light lamp
warning light
push up video/
push down to
stop recording
PTTintercom
record key
power switch
battery latch
Replace the
battery grip
camera2
display screen
menu
home page
return key
emphasis mark
photo/infrared
light button
white light/
volume plus
FN/Volume down
SOS

Quick description of key functions

①【Video button】Push up to start recording, push down to end recording; ②【PTT intercom key】one-to-one intercom, terminal device and platform terminal Sound intercom; ③【Record button】Press to start or end recording; ④【Power button】long press three seconds, you can open, shut down, restart; click Open and close the screen, and enter the standby after closing the screen; ⑤【Key mark key】Click on the ongoing video recording file forward Line IMP mark, important mark; ⑥【Photo/infrared Light key】Short press to take a photo, and long press to turn on or off the infrared light; ⑦【White light/volume + key】Short press to adjust the volume +, long press to turn on or off the white light; ⑧【FN/ Volume - key】Press and adjust Volume -; ⑨【SOS key】Press to push the rescue signal to the platform, turn on the red and blue flashing light at the same time, record the video under the SOS state Sound, photos and other generated files for SOS marking, important marking, platform cloud services at the same time to store files.