尺寸:75X105mm 直角

按键指示说明



功能按键快捷说明

①【录像/红外灯键】短按进行录像,再次短按结束录像;长按打开或关闭红外灯②【录音键】短按进行录音,再次短按结束录音;③【多功能/白光灯键】可以自定义的按键,短按打开白光灯,再次短按关闭白光灯;④【电源键】长按三秒,即可开、关机,重启;点按打开、关闭屏幕,关闭屏幕后进入待机;⑤【对讲键】一对一对讲,终端设备与平台端语音对讲;⑥【拍照键】短按拍照;⑦【指纹识别】对录入指纹进行识别;⑧【SOS键】长按打开或者关闭红蓝爆闪灯,并向平台推送救助信号,对SOS状态下录像,录音,拍照等产生的文件进行SOS标记,重要标记,平台云服务同时存储文件。

KEY INDICATION



Quick description of key functions

①【Record/Infrared Light Button】Short press to start recording, short press again to stop recording; long press to turn the infrared light on or off.②【Recording Button】Short press to start audio recording, short press again to stop recording.③【Multi-function/White Light Button】A customizable button; short press to turn the white light on, short press again to turn it off.④【Power Button】Long press for 3 seconds to power on, power off, or restart; tap to turn the screen on or off, and the device enters standby mode after the screen is turned off.⑤【Intercom Button】Enables one-to-one intercom, allowing voice communication between the terminal device and the platform.⑥【Camera Button】Short press to take a photo.⑦【Fingerprint Recognition】Recognizes registered fingerprints.
⑧【SOS Button】Long press to turn the red-blue flashing lights on or off and send a rescue signal to the platform; files generated by video recording, audio recording, photo-taking, etc., in the SOS state will be marked with SOS (as important marks) and simultaneously stored in the platform's cloud service.